
FCC Information and Copyright

This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. There is no guarantee that interference will not occur in a particular installation.

The vendor makes no representations or warranties with respect to the contents here of and specially disclaims any implied warranties of merchantability or fitness for any purpose. Further the vendor reserves the right to revise this publication and to make changes to the contents here of without obligation to notify any party beforehand.

Duplication of this publication, in part or in whole, is not allowed without first obtaining the vendor's approval in writing.

The content of this user's manual is subject to be changed without notice and we will not be responsible for any mistakes found in this user's manual. All the brand and product names are trademarks of their respective companies.

Table of Contents

Notice	1
Mainboard Features	2
1. Features Introduction.....	2
1-1. Hardware.....	2
1-2. BIOS & Software.....	6
1-3. Package Contents.....	6
2. Mainboard Configuration.....	7
2-1. Layout of U8968.....	7
2-2. Component Index.....	8
3. CPU Configuration	9
3-1. CPU Socket 478 Configuration Steps:	9
3-2. CPU Fan Header: JCFAN1.....	11
3-3. System Fan Header: JSFAN1	11
4. Jumpers, Headers & Connectors.....	12
4-1. Front Panel Connector: JPANEL1.....	13
4-2. ATX 20-pin Power Connector: JATXPWR1.....	15
4-3. Hard Disk Connectors: IDE1/IDE2	15
4-4. Floppy Disk Connector: FDD1.....	16
4-5. Wake On LAN Header: JWOL1.....	16
4-6. Clear CMOS Jumper: JCMOS1	16
4-7. Front USB Header: JUSB3.....	17
4-8. Front USB Header: JUSB4.....	17
4-9. 5V / 5VSB Selection for KB: JKBV1.....	17

Table of Contents

4-10. ATX 12V Power Connector: JATXPWR2.....	18
4-11. 5V / 5VSB Selection for USB: JUSBV1.....	18
4-12. 5V / 5VSB Selection for USB: JUSBV3.....	18
4-13. 5V / 5VSB Selection for USB: JUSBV4.....	18
4-14. Front 1394 Header: J1394A1(Optional)	19
4-15. Front 1394 Header: J1394B1(Optional)	19
4-16. Front 1394 Header: J1394C1(Optional)	19
4-17. CNR Codec Primary/Secondary Selection: JCODECSEL.....	20
5. RAM Module Configuration	21
5-1. DDR SDRAM	21
5-2 SDRAM	22
5-3. How to install DDR/SDRAM DIMM Module	23
6. Peripheral Port Features	25
6-1. PS/2 Mouse / Keyboard Connector: JKBMS1.....	25
6-2. USB & LAN Port Connectors: JUSBLAN1	26
6-3. Serial and Parallel Interface Ports	28
6-4. Game (Joystick/MIDI) Port Connector: JAUD_GAME	30
6-5. Audio Port Connectors: JSPKR1/JLIN1/JMIC1	30
6-6. Audio Subsystem	31
WarpSpeeder	33
Introduction.....	33
System Requirement.....	34
Installation	34
Usage.....	36

Notice

Introduction of system

This mainboard is designed to take advantage of the latest industry technology to provide you with the ultimate solution in data processing. In the tradition of its predecessors, this mainboard continues a commitment to reliability and performance and strives for full compliance and compatibility with industry software and hardware standards.

U8968 Features:

- 1.Contains on board I/O facilities that include two serial ports, a parallel port, a PS/2 mouse port, a PS/2 keyboard port, audio ports, USB ports and a game port.
- 2.Contains on board IDE facilities for IDE devices such as hard disks and CD-ROM Drives.
- 3.Supports the Intel Pentium® 4 processor, a leading edge processor. Complies with PC ATX form factor specifications.
- 4.Supports popular operating systems such as Windows NT, Windows 2000, Windows ME, Windows XP, Novell, LINUX and SCO UNIX.

Mainboard Features

1. Features Introduction

1-1. Hardware

CPU:

1. Provides Socket-478.
2. Supports the Intel Pentium® 4 processor providing the new generation power for high-end workstations and servers.

Speed:

1. Running at 400/ 533 MHz Front Side Bus frequency.
2. Supports up to 2.8 GHz CPU core speeds.
3. The 33MHz 32 bit PCI 2.2 compliant.
4. The 66MHz AGP 2.0 compliant interface supports 1x, 2x and 4x data transfer mode.

Chipset:

Chipset – VIA VT8753E (P4X266E)/ VT8235.

Super I/O

Chipset – ITE IT8705.

DRAM Memory:

1. Supports 200MHz, 266MHz DDR SDRAM or PC100, PC133 SDRAM.
2. Supports 64Mb, 128Mb, 256Mb and 512Mb technologies for x8 and 16 devices.
3. The largest memory capacity is 2 GB.

Shadow RAM:

Motherboard is equipped with a memory controller providing shadow RAM and support for ROM BIOS.

Green Functionality:

- 1.Supports Award BIOS™ power management functionality.
- 2.Has a power down timer from 1 to 15 minutes.

BUS Slots:

- 1.Contains 1 AGP slot.
- 2.Contains 1 CNR slot.
3. Contains 5 32-bit PCI bus slots

Fast EtherNet 10/ 100 1-Port PHY/ Transceiver:

- 1.Dual Speed – 100/ 10 Mbps.
- 2.Half and Full Duplex.
- 3.MII Interface to Ethernet Controller.
- 4.Optional Repeater Interface.
- 5.Auto Negotiation: 10/ 100, Full/ Half Duplex.
- 6.Meet All Applicable IEEE 802.3, 10Base-Tx Standards.
- 7.Baseline Wander Correction.

Flash Memory:

- 1.Supports flash memory functionality.
- 2.Supports ESCD functionality.

Built in IDE Facilities:

- 1.Supports four IDE hard disk drives.
- 2.Supports PIO Mode 4, Master Mode, and high performance hard disk drives.
- 3.Supports disk transfer rates up to 133 MB/second.

- 4.Supports Ultra DMA 33, Ultra DMA 66, Ultra DMA 100, Ultra DMA 133 Bus Master Modes.
- 5.Supports IDE interface with CD-ROM.
- 6.Supports high capacity hard disk drives.
- 7.Supports LBA mode.

AC'97 Sound Codec Onboard:

- 1.AC-LINK protocol compliance.
- 2.Compliant with AC'97 specification.
- 3.18-bit full duplex stereo ADC, DACs.
- 4.SNR>95 Bb throughmixer and DAC.

Hardware Audio CMI 8738 (Optional):

- 1.6CH DAC for AC3®.
- 2.HRTF-based 3D positional audio, supporting DirectSound™ 3D and A3D™ interface.
- 3.Supports 4.1/ 5.1 speakers, C3DX positional audio in 4/ 6CH speaker mode.
- 4.MPU-401 port.
- 5.Built-in ZV port.

1394 Function (Optional)

- 1.OHCI Compliant Programming Interface.
- 2.Compliant with 1394 Open HCI Specifications v1.0 and v1.1.
- 3.Descriptor based isochronous and asynchronous DMA channels for receive/ transmit packets.
- 4.32-Bit Power-Managed PCI Bus Interface.
- 5.Compliant with PCI specification v2.2.
- 6.Integrated 400 Mbit 3-Port PHY.
- 7.Supports provisions of IEEE 1394-1995 Standard.
- 8.Fully interoperable with IEEE Std 1394-1995 devices.

I/O facilities:

- 1.One multi-mode Parallel Port capable of supporting the following specifications:
 - Standard & Bidirection Parallel Port.
 - Enhanced Parallel Port (EPP).

*Extended Capabilities Port (ECP).
Normal*

- 2.Supports one serial port, 16550 UART.*
- 3.Supports Infrared Data Transmission using IrDA.*
- 4.Supports PS/2 mouse and PS/2 keyboard.*
- 5.Supports 360KB, 720KB, 1.2MB, 1.44MB, and 2.88MB floppy disk drives.*

Universal Serial Bus:

Supports two back panel Universal Serial Bus (USB2.0) Ports and four front panel Universal Serial Bus (USB2.0) Ports.

Hardware Monitor Function:

- 1.Monitors CPU Fan Speed.*
- 2.Monitors System Voltage.*
- 3.Monitors System Speed.*

Dimensions (ATX form-factor):

24.5cm x 29.5cm (WxL)

1-2. BIOS & Software

1. Award legal BIOS.
2. Supports APM1.2.
3. Supports USB Function.
4. Supports ACPI.

Operating System:


Offers the highest performance for MS-DOS, Windows NT, Windows 2000, Windows ME, Windows XP, Novell, LINUX, and SCO UNIX etc.

1-3. Package Contents


1. HDD Cable.
2. FDD Cable.
3. Flash Memory Writer for BIOS Update.
4. USB Cable (Optional).
5. Rear I/O Panel for MATX Case (Optional).
6. Fully Setup Driver CD.

2. Mainboard Configuration

2-1. Layout of U8968




2-2. Component Index




3. CPU Configuration

3-1. CPU Socket 478 Configuration Steps:



1. Pull the lever sideways away from the socket then raise the lever up to a 90-degree angle.
2. Locate Pin A in the socket and look for the white dot or cut edge in the CPU. Match Pin A with the white dot/cut edge then insert the CPU.
3. Press the lever down. Then Put the fan on the CPU and buckle it and put the fan's power port into the JCFAN1, then to complete the installation.

CPU Configuration Layout




3-2. CPU Fan Header: J CFAN1

Pin No.	Assignment
1	Ground
2	+12V
3	Sense

3-3. System Fan Header: J SFAN1

Pin No.	Assignment
1	Ground
2	+12V
3	Sense

4. Jumpers, Headers & Connectors



4-1. Front Panel Connector: J PANEL1

Pin No.	Assignment	Function	Pin No.	Assignment	Function
1	+5V	Speaker Connector	2	Sleep Control	Sleep Button
3	NA		4	Ground	
5	NA		6	NA	NA
7	Speaker		8	Power LED (+)	POWER LED
9	HDD LED (+)	Hard Drive LED	10	Power LED (+)	
11	HDD LED (-)		12	Power LED (-)	
13	Ground	Reset Button	14	Power Button	Power-on Button
15	Reset Control		16	Ground	
17	NA		18	KEY	
19	NA	IrDA Connector	20	KEY	IrDA Connector
21	VCC5		22	Ground	
23	IRTX		24	IRRX	

SPK (Speaker Connector)

An offboard speaker can be installed on the motherboard as a manufacturing option. An offboard speaker can be connected to the motherboard at the front panel connector. The speaker (onboard or offboard) provides error beep code information during the Power On Self-Test when the computer cannot use the video interface. The speaker is not connected to the audio subsystem and does not receive output from the audio subsystem.

RST (Reset Button)

This connector can be attached to a momentary SPST switch. This switch is usually open and when closed will cause the motherboard to reset and run the POST (Power On Self Test).

POW-LED (Power LED Connector)

This connector can be attached to an LED on the front panel of a computer case. The LED will illuminate while the computer is powered on.

HLED (Hard Drive LED Connector)

This connector can be attached to an LED on the front panel of a computer case. The LED will flicker during disk activity. This disk activity only applies to those IDE drives directly attached to the system board.

IR (Infrared Connector)

This connector is used to attach to an infrared sensing device. After the IrDA interface is configured, connectionless data transfer to and from portable devices such as laptops, PDAs is possible.

SLP (Sleep/ Green Button)

This connector is used to conserve energy by powering down the monitor and the hard disk when not in use. To configure this option, you need to connect a button from the front panel to this connector. Depressing the button will power down the monitor and hard drives until the system is invoked by any keyboard activity, mouse activity, modem activity or when the sleep button is depressed again. APM (Advanced Power Management) must be enabled in the system BIOS and the APM driver must be loaded.

ON/ OFF (Power Button)

This connector can be attached to a front panel power switch. The switch must pull the Power Button pin to ground for at least 50 ms to signal the power supply to switch on or off. (The time required is due to internal debounce circuitry on the system board). At least two seconds must pass before the power supply will recognize another on/off signal.

4-2. ATX 20-pin Power Connector: JATXPWR1

PIN	Assignment	PIN	Assignment
1	+3.3V	11	+3.3V
2	+3.3V	12	-12V
3	Ground	13	Ground
4	+5V	14	PS_ON
5	Ground	15	Ground
6	+5V	16	Ground
7	Ground	17	Ground
8	PW_OK	18	-5V
9	+5V_SB	19	+5V
10	+12V	20	+5V

4-3. Hard Disk Connectors: IDE1/ IDE2

This mainboard has a 32-bit Enhanced PCI IDE Controller that provides PIO Mode 0~4, Bus Master, and Ultra DMA / 33, Ultra DMA / 66, Ultra DMA / 100 functionality. It has two HDD connectors IDE1 (primary) and IDE2 (secondary).

- **IDE1 (Primary IDE Connector)**

The first hard drive should always be connected to IDE1. IDE1 can connect a Master and a Slave drive. You must configure the second hard drive on IDE1 to Slave mode by setting the jumper accordingly.

- **IDE2 (Secondary IDE Connector)**

The IDE2 controller can also support a Master and a Slave drive. The configuration is similar to IDE1. The second drive on this controller must be set to slave mode.



4-4. Floppy Disk Connector: FDD1

The motherboard provides a standard floppy disk connector (FDC) that supports 360K, 720K, 1.2M, 1.44M and 2.88M floppy disk types. This connector supports the provided floppy drive ribbon cables.

4-5. Wake On LAN Header: J WOL1

Pin No.	Assignment
1	+5V SB
2	Ground
3	Wake up

4-6. Clear CMOS Jumper: J CMOS1

J CMOS1	Assignment
 1-2 Closed	Normal Operation (default)
 2-3 Closed	Clear CMOS Data



The following procedures are for resetting the BIOS password. It is important to follow these instructions closely.

※ Clear CMOS Procedures:

1. Remove AC power line.
2. Make J CMOS1 (2-3) closed.

3. Wait for five seconds.
4. Make JCMOS1 (1-2) closed.
5. Let AC power on.
6. Reset your desired password or clear the CMOS data.

4-7. Front USB Header: J USB3

(JUSB3)



Pin	Assignment	Pin	Assignment
1	+5V(fused)	2	+5V(fused)
3	USBP2-	4	USBP3-
5	USBP2+	6	USBP3+
7	Ground	8	Ground
9	KEY	10	NC

4-8. Front USB Header: J USB4

(JUSB4)

Pin	Assignment	Pin	Assignment
1	+5V(fused)	2	+5V(fused)
3	USBP2-	4	USBP3-
5	USBP2+	6	USBP3+
7	Ground	8	Ground
9	KEY	10	NC



4-9. 5V / 5VSB Selection for KB: J KBV1

J KBV1	Assignment
 1-2 Closed	5V
 2-3 Closed	5V_SB



4-10. ATX 12V Power Connector: JATXPWR2

PIN	Assignment	PIN	Assignment
1	+12V	3	Ground
2	+12V	4	Ground



4-11. 5V / 5VSB Selection for USB: JUSBV1

JUSBV1	Assignment
 1-2 Closed	5V
 2-3 Closed	5V_SB

4-12. 5V / 5VSB Selection for USB: JUSBV3

JUSBV3	Assignment
 1-2 Closed	5V
 2-3 Closed	5V_SB

4-13. 5V / 5VSB Selection for USB: JUSBV4

JUSBV4	Assignment
 1-2 Closed	5V
 2-3 Closed	5V_SB

4-14. Front 1394 Header: J 1394A1(Optional)

Pin	Assignment	Pin	Assignment
1	A+	2	A-
3	Ground	4	Ground
5	B+	6	B-
7	+12V	8	+12V
9	KEY	10	Ground

4-15. Front 1394 Header: J 1394B1(Optional)

Pin	Assignment	Pin	Assignment
1	A+	2	A-
3	Ground	4	Ground
5	B+	6	B-
7	+12V	8	+12V
9	KEY	10	Ground

4-16. Front 1394 Header: J 1394C1(Optional)

Pin	Assignment	Pin	Assignment
1	A+	2	A-
3	Ground	4	Ground
5	B+	6	B-
7	+12V	8	+12V
9	KEY	10	Ground

4-17. CNR Codec Primary/ Secondary Selection: J CODECSEL

Pin No.	Assignment
1-2	On-board Primary Codec
2-3	CNR Primary Codec

5. RAM Module Configuration

5-1. DDR SDRAM

DRAM Access Time: 2.5V Unbuffered DDR SDRAM
PC1600/ PC2100 Type required.

DRAM Type: 128MB/ 256MB/ 512MB/ 1GB DIMM
Module (184 pin)

**Total Memory Size with unbuffer
DIMMs**

(Only for reference)

DIMM Socket Location	DDR Module	Total Memory Size (MB)
DDR 1	64MB/128MB/256MB/512MB/1GB *1	Max is 2GB
DDR 2	64MB/128MB/256MB/512MB/1GB *1	

5-2 SDRAM

DRAM Access Time: 3.3V Unbuffered SDRAM PC100/
PC133 Type required.

DRAM Type: 128MB/ 256MB/ 512MB/ 1GB DIMM
Module (168 pin)

Total Memory Size with unbuffer DIMMs

(Only for reference)

DIMM Socket Location	SDR Module	Total Memory Size (MB)
SDR 1	64MB/128MB/256MB/512MB/1GB *1	Max is 2GB
SDR 2	64MB/128MB/256MB/512MB/1GB *1	


⚡ When you use DDR SDRAM, the memory power will automatically set to 2.5V.

⚡ When you use SDRAM, the memory power will automatically set to 3.3V.


⚡ For the above settings, you can only use one kind of memory on this motherboard. It is forbidden to insert both kind of memory simultaneously. You must insert only DDR or SDRAM.

5-3. How to install DDR/ SDRAM DIMM Module

DDR SDRAM:




Single Sided DIMM




Double Sided DIMM

1. The DDR DIMM socket has a "Plastic Safety Tab", and the DDR DIMM memory module has an Asymmetrical notch", so the DDR DIMM memory module can only fit into the slot in one direction.




2. Push the tabs out. Insert the DDR DIMM memory modules into the socket at a 90-degree angle, then push down vertically so that it will fit into the place.




3. The Mounting Holes and plastic tabs should fit over the edge and hold the DDR DIMM memory modules in place.


SDRAM:



1. The SDRAM DIMM socket has a "Plastic Safety Tab", and the SDRAM DIMM memory module has an Asymmetrical notch", so the SDRAM DIMM memory module can only fit into the slot in one direction.




2. Push the tabs out. Insert the SDRAM DIMM memory modules into the socket at a 90-degree angle, then push down vertically so that it will fit into the place.



3. The Mounting Holes and plastic tabs should fit over the edge and hold the SDRAM DIMM memory modules in place.

6. Peripheral Port Features



6-1. PS/ 2 Mouse / Keyboard Connector: JKBMS1


The motherboard provides a standard PS/2 mouse / Keyboard mini DIN connector for attaching a PS/2 mouse. You can plug a PS/2 mouse / Keyboard directly into this connector. The connector location and pin definition are shown below:

PS/ 2 Mouse / Keyboard Connectors

Pin	Assignment
1	Data
2	No connect
3	Ground
4	+5 V (fused)
5	Clock
6	No connect

6-2. USB & LAN Port Connectors: J USBLAN1

6-2-1. USB Connectors:



USB Connector (the below one)


Pin	Assignment
1	+5 V (fused)
2	USBP1-
3	USBP1+
4	Ground

USB Connector (the above one)

Pin	Assignment
5	+5 V (fused)
6	USBP2-
7	USBP2+
8	Ground

6-2-2. LAN Port Connector (Optional)

This connector allows you to connect to the Internet through a Local Area Network (LAN). You can set up the connection by entering account information provided by your ISP.



LAN Port Connector

Pin	Assignment
9	VCC3
10	TD+
11	TD-
12	RD+
13	RD-
14	NC

6-3. Serial and Parallel Interface Ports

This system comes equipped with one serial port and one parallel port. Both types of interface ports will be explained in this chapter.

6-3-1. The Serial Interface: JCOM1/ JCOM2

The serial interface port is sometimes referred to as an RS-232 port or an asynchronous communication port. Mice, printers, modems and other peripheral devices can be connected to a serial port. The serial port can also be used to connect your computer with another computer system.

Connectivity

The serial ports can be used in many ways, and it may be necessary to become familiar with the pinout diagram. The following chart gives you the function of each pin on the 9-pin connector and some of the 25-pin connector. This information can be used when configuring certain software programs to work with the serial ports.

Signal	Name	DB9 PIN	DB25 PIN
DCD	Data Carrier Detect	1	8
RX	Receive Data	2	3
TX	Transmit Data	3	2
DTR	Data Terminal Ready	4	20
GND	Signal Ground	5	7
DSR	Data Set Ready	6	6
RTS	Request to Send	7	4
CTS	Clear to Send	8	5
RI	Ring Indicator	9	22


6-3-2. Parallel Interface Port: J PRNT1

Unlike the serial ports, parallel interface port has been standardized and should not present any difficulty interfacing peripherals to your system. Sometimes called centronics port, the parallel port is almost exclusively used with printers. The parallel port on your system has a 25-pin, DB25 connector. The pinout for the parallel port are shown in the table below.


Pin	Signal
1	-Strobe
2	Data 0
3	Data 1
4	Data 2
5	Data 3
6	Data 4
7	Data 5
8	Data 6
9	Data 7
10	-Ack
11	Busy
12	Paper Empty
13	+Select
14	-Auto FDXT
15	-Error
16	-Init
17	-SLCTN
18	Ground
19	Ground
20	Ground
21	Ground
22	Ground
23	Ground
24	Ground
25	Ground

6-4. Game (Joystick/ MIDI) Port Connector: JAUD_GAME

This connector allows you to connect a joystick or game pad for playing computer games. Also, you may play or edit professional music by connecting MIDI devices.




6-5. Audio Port Connectors: JSPKR1/ JLIN1/ JMIC1



1. **Speaker Out** is used to connect speakers or headphones for audio output.
2. **Line In** can be connected to the external CD player, Tape player or other audio devices for audio input.
3. **Mic In** is used to connect a microphone, which allows you to input sounds and voices.

6-6. Audio Subsystem



6-6-1. CD-ROM Audio-In Header: JCDIN1

Pin No.	Assignment
1	Left Channel Input
2	Ground
3	Ground
4	Right Channel Input

6-6-2. Front Panel Audio Header: JAUDIO1

Pin No.	Assignment	Pin No.	Assignment
1	Mic In	2	Ground
3	Mic Power	4	Audio Power
5	RT Line Out	6	RT Line Out
7	Reserved	8	
9	LFT Line Out	10	LFT Line Out

6-6-3. Digital Audio Connector: JSPDIF_OUT

Pin No.	Assignment
1	5V
2	SPDIF_OUT
3	Ground

WarpSpeeder



Introduction

[WarpSpeeder™], a new powerful control utility, features three user-friendly functions including Overclock Manager, Overvoltage Manager, and Hardware Monitor.

With the Overclock Manager, users can easily adjust the frequency they prefer or they can get the best CPU performance with just one click. The Overvoltage Manager, on the other hand, helps to power up CPU core voltage and Memory voltage. The cool Hardware Monitor smartly indicates the temperatures, voltage and CPU fan speed as well as the chipset information. Also, in the About panel, you can get detail descriptions about BIOS model and chipsets. In addition, the frequency status of CPU, memory, AGP and PCI along with the CPU speed are synchronically shown on our main panel.

Moreover, to protect users' computer systems if the setting is not appropriate when testing and results in system fail or hang, [WarpSpeeder™] technology assures the system stability by automatically rebooting the computer and then restart to a speed that is either the original system speed or a suitable one.


System Requirement

OS Support: Windows 98 SE, Windows Me, Windows 2000, Windows XP


DirectX: DirectX 8.1 or above. (The Windows XP operating system includes DirectX 8.1. If you use Windows XP, you do not need to install DirectX 8.1.)

Installation

1. Execute the setup execution file, and then the following dialog will pop up. Please click "Next" button and follow the default procedure to install.



2. When you see the following dialog in setup procedure, it means setup is completed. If the “Launch the WarpSpeeder Tray Utility” checkbox is checked, the Tray Icon utility and [WarpSpeeder™] utility will be automatically and immediately launched after you click “Finish” button.




Usage

The following figures are just only for reference, the screen printed in this user manual will change according to your motherboard on hand.


[WarpSpeeder™] includes 1 tray icon and 5 panels:

1. Tray Icon:

Whenever the Tray Icon utility is launched, it will display a little tray icon on the right side of Windows Taskbar.



This utility is responsible for conveniently invoking [WarpSpeeder™] Utility. You can use the mouse by clicking the left button in order to invoke [WarpSpeeder™] directly from the little tray icon or you can right-click the little tray icon to pop up a popup menu as following figure. The “Launch Utility” item in the popup menu has the same function as mouse left-click on tray icon and “Exit” item will close Tray Icon utility if selected.



2. Main Panel

If you click the tray icon, [WarpSpeeder™] utility will be invoked. Please refer

do the following figure; the utility's first window you will see is Main Panel.

Main Panel contains features as follows:

- Display the CPU Speed, CPU external clock, Memory clock, AGP clock, and PCI clock information.
- Contains About, Voltage, Overclock, and Hardware Monitor Buttons for invoking respective panels.
- With a user-friendly Status Animation, it can represent 3 overclock percentage stages:

Man walking => overclock percentage from 100% ~ 110 %

Panther running => overclock percentage from 110% ~ 120%

Car racing => overclock percentage from 120% ~ above



3. Voltage Panel

Click the Voltage button in Main Panel, the button will be highlighted and the Voltage Panel will slide out to up as the following figure.

In this panel, you can decide to increase CPU core voltage and Memory voltage or not. The default setting is "No". If you want to get the best performance of overclocking, we recommend you click the option "Yes".



4. Overclock Panel


Click the Overclock button in Main Panel, the button will be highlighted and the Overclock Panel will slide out to left as the following figure.

Overclock Panel contains the these features:

- a. “-3MHz button”, “-1MHz button”, “+1MHz button”, and “+3MHz button”: provide user the ability to do real-time overclock adjustment.

Warning: Manually overclock is potentially dangerous, especially when the overclocking percentage is over 110 %. We strongly recommend you verify every speed you overclock by click the Verify button. Or, you can just click Auto overclock button and let [WarpSpeeder™] automatically gets the best result for you.

- b. “Recovery Dialog button”: Pop up the following dialog. Let user select a restoring way if system need to do a fail-safe reboot.



- c. “Auto-overclock button”: User can click this button and [WarpSpeeder™] will set the best and stable performance and frequency automatically. [WarpSpeeder™] utility will execute a series of testing until system fail. Then system will do fail-safe reboot by using Watchdog function. After reboot, the [WarpSpeeder™] utility will restore to the hardware default setting or load the verified best and

stable frequency according to the Recovery Dialog's setting.

- d. "Verify button": User can click this button and [WarpSpeeder™] will proceed a testing for current frequency. If the testing is ok, then the current frequency will be saved into system registry. If the testing fail, system will do a fail-safe rebooting. After reboot, the [WarpSpeeder™] utility will restore to the hardware default setting or load the verified best and stable frequency according to the Recovery Dialog's setting.

Note: Because the testing programs, invoked in Auto-overclock and Verify, include DirectDraw, Direct3D and DirectShow tests, the DirectX 8.1 or newer runtime library is required. And please make sure your display card's color depth is High color (16 bit) or True color(24/32 bit) that is required for Direct3D rendering.



5. Hardware Monitor Panel

Click the Hardware Monitor button in Main Panel, the button will be highlighted and the Hardware Monitor panel will slide out to left as the following figure.

In this panel, you can get the real-time status information of your system. The information will be refreshed every 1 second.



6. About Panel

Click the About button in Main Panel, the button will be highlighted and the About Panel will slide out to up as the following figure.

In this panel, you can get model name and detail information in hints of all the chipset that are related to overclocking. You can also get the mainboard's BIOS model and the Version number of [WarpSpeeder™] utility.



Note: Because the overclock, overvoltage, and hardware monitor features are controlled by several separate chipset, [WarpSpeeder™] divide these features to separate panels. If one chipset is not on board, the correlative button in Main panel will be disabled, but will not interfere other panels' functions. This property can make [WarpSpeeder™] utility more robust.

10/24/2002

